



(CZ) Výška dveří / (SK) Výška dverí / (PL) Wysokość drzwi / (DE) Türhöhe

695 mm: 6132149, 6132154, 6132159, 6132164, 6132169, 6132174, 6132179, 6132184, 6132189

1042 mm: 6132150, 6132155, 6132160, 6132165, 6132170, 6132175, 6132180, 6132185, 6132190

1393 mm: 6132152, 6132157, 6132162, 6132167, 6132172, 6132177, 6132182, 6132187, 6132192







J	K	L	M	N	O	P
4×	4×	12×	2×	1×	1×	2×
		Ø 3,5 x 16				


(CZ) Součástky **K** a **O** namontujte na korpus Vaší skříně a dále pokračujte v montáži dveří dle návodu.

(SK) Súčiastky **K** a **O** namontujte na korpus Vašej skrine a dále pokračujte v montáži dverí dle návodu.

(PL) Zamontuj elementy **K** i **O** na korpusie szafki i kontynuuj montaż drzwi zgodnie z instrukcją.


(DE) Montieren Sie die Bauteile **K** und **O** am Korpus Ihres Schrankes und fahren Sie mit der Montage der Tür gemäß der Anleitung fort.





3

1



2

