














WISCHELTISCH




- a  1
71x
- b  2
71x
- c  3
4*18mm
4x
- d  4
4x
- e  5
6*40mm
2x
- f  6
2x
- g  7
6x
- h  8
16mm
50x
- i  9
2x
- j  10
2x
- k  11
71x


1




2




3




4




5






6





7





8



9



10



11

